



HDMI® 4K Extender

Vanco Part Number: HD4KEX30

Technical Support
www.vanco1.com • techsupport@vanco1.com • 800-626-6445



DEAR CUSTOMER

Thank you for purchasing this product.

For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

This product is 100% inspected and tested in the United States to verify HDMI performance parameters.

WARNING

- Do not expose this unit to water, moisture, or excessive humidity.
- Do not install or place this unit in a built-in cabinet, or other confined space without adequate ventilation.
- To prevent risk of electrical shock or fire hazard, due to overheating, do not obstruct unit's ventilation openings.
- 4. Do not install near any source of heat, including other units that may produce heat.
- 5. Do not place unit near flames.

- 6. Only clean unit with a dry cloth.
- Unplug unit during lightening storms, or when not used for an extended period of time. A surge protector is strongly recommended
- 8. Protect the power cord from being walked on or pinched, particularly at the plugs.
- Use unit only with accessories specified by the manufacturer
- 10. Refer all servicing to qualified personnel.

CAUTION

HDMI is a very complex technology requiring continuous authentication of the signal and the same video resolution and audio settings on all electronic equipment in the system. When there are multiple sources and displays, the video resolution and audio setting on all connected units must be adjusted to correspond with that of the display having the lowest video and audio capability.

FEATURES

The Vanco HD4KEX30 HDMI 4K Extender, extends 4K@60Hz and HDR up to 98ft/30m over a single Cat5e/6 cable. Also able to pass 4K@30Hz and 1080p@60Hz up to 164ft/50m. No EDID or EQ adjustments are necessary as the units automatically adjust for compatibility and gain. In addition, IR pass-through allows for the source to be able to be controlled from the remote display. For extending full 4K resolution up to 60Hz, 4:2:0 chroma subsampling, and HDR, the HD4KEX30 is a great plug and play solution for connecting the latest 4K components!

The HD4KEX30 includes two units: transmitting unit (HD4KEX30-TX) and receiving unit (HD4KEX30-RX). The transmitting unit is used to capture the HDMI input with IR signals and carries the signals via one cost effective Cat5e/6 cable. The receiving unit is responsible for equalizing the transmitted HDMI signal and reconstructing IR signals. The HD4KEX30 offers a convenient solution for 4K extension over a single Cat5e/6, and is the perfect solution for any application.

HDMI® 4K Extender Part # HD4KEX30

- Allows HDMI audio/video and control to be transmitted using a single Cat5e or Cat6 cable
- Supports 4K@60Hz, 4:2:0 Chroma up to 98ft/30m
- Supports 4K@30Hz and 1080p@60Hz up to 164ft/50m
- Passes High Dynamic Range (HDR)
- HDCP 2.2/1.4 Compatible
- Supports IR callback from display to source
- Audio Support: LPCM 7.1, Dolby® TrueHD, Dolby Digital® Plus, and DTS-HD Master Audio™
- Plug and play installation with auto EDID/EQ management
- Power supplies: (2) 5V DC
- Dimensions: 2" W x .6" H x 3" D



SPECIFICATIONS


HDMI Compliance	. HDMI 2.0
HDCP Compliance	. HDCP 2/2/1.4
Transmission Medium	. Cat5e/6
Transmission Distance	. 4K@30Hz up to 164ft/50m; 4K@60Hz up to
Video Bandwidth	. 10.2Gbps
Video Support	
Audio SupportDTS-HD Master Audio™	. LPCM 7.1, Dolby® TrueHD, Dolby Digital® Plus, and
Dimensions	. 77mm x 50mm x 15.6mm
Net Weight	. TX: 80g; RX: 80g
Power Supply	. 5V/2A
Power Consumption	. 5W
Operation Temperature	. 32~104 Fahrenheit; 0~40 Celsius
Storage Temperature	4~158 Fahrenheit; -20~70 Celsius
Relative Humidity	. 0%~95% (no condensation)

PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- HD4KEX30 (TX & RX)
- IR Transmitter (IR TX)
- IR Receiver (IR RX)
- Mounting Accessories
- (2) 5V/1A Power Supplies
- Product Manual

PANEL DESCRIPTIONS TRANSMITTER:





- 1. Reset Button: Press to reboot unit (instead of unplugging power supply)
- Cat5e/6 Output: Connect a single Cat5e/6 cable to connect to Receiver unit (home run cable recommended)
- 3. Power LED Indicator
- 4. 5V Power Supply Connection: Connect included Power Supply (Connecting an incorrect power supply may result in failure of the unit)
- 5. HDMI Input: Connect the source to this input
- 6. IR Out: Connect the included IR TX (Transmitter) for IR Source control, see IR section for installation and correct placement




RECEIVER:





- 1. Reset Button: Press to reboot unit (instead of unplugging power supply)
- Cat5e/6 Input: Connect a single Cat5e/6 cable to connect to Transmitter unit (home run cable recommended)
- 3. Power LED Indicator
- 4. 5V Power Supply Connection: Connect included Power Supply (Connecting an incorrect power supply may result in failure of the unit)
- 5. HDMI Output: Connect the display to this output
- 6. IR In: Connect the included IR RX (Receiver) for IR Source control, see IR section for installation and correct placement

CONNECT AND OPERATE



- Connect a source such as a Blu-Ray Player, game console, AV Receiver, Cable or Satellite Receiver, etc. to the HDMI input on the Transmitting unit
- 2. Connect a display such as an HDTV or HD Projector to the HDMI output on the Receiving unit
- Connect a single Category 5e/6/7 (up to 164FT/50M for 1080p/4k@30Hz or 98ft/30m for 4K@60Hz)
 cable to the UTP output of the Transmitting unit, and the other end to the UTP input of the Receiving unit
- OPTIONAL: When using IR control, connect the IR Transmitter (IR TX) to the IR OUT port on the transmitting unit (HD4KEX30-TX); connect the IR Receiver (IR RX) to the IR IN port on the receiving unit (HD4KEX30-RX)
- 5. Connect power to both the transmitter and receiver
- 6. Turn on the source and display

At this point the display connected should display the source signal connected to the extender set. If no signal is being displayed, connect a shorter Cat5e/6 cable (jumper or patch cable). If a display is having difficulty receiving a signal, access the source's menu and adjust the resolution (lowest to highest until signal is displayed). Use the source remote at the receiver emitter to test IR functionality. If the IR remote function is not responding, check the emitters to ensure they are placed correctly and are plugged into the correct IR tacks on the Extender set receiving and transmitting units.



IR PASS THROUGH

The IR system allows you to control the source that is connected to the extender unit, from the display. There are two important things to note when setting up the IR system:

- 1. The IR Receiver (IR RX) is always what you point your remote at to send an IR signal. This pigtail is placed at the display for controlling the source
- 2. The IR Transmitter (IR TX) is what sends the IR signal to what you are intending to control. This pigtail is placed at the source; either pointed at the source, or placed on the front panel of the source (see below for placement tips)



IR TRANSMITTER (TX)

To control the source: Plug IR Blaster into IR OUT port of transmitter unit (HD4KEX30-TX); place blaster in front of the IR eye of the source

Note: Placement of the IR Blaster is important and can result in the IR system not working if improperly placed.

- First, locate the IR eye or window on the source
- If placing the IR blaster right on the front panel of the source, do not stick right on top of
 the IR eye or IR window. The IR signal cannot travel through the double-sided tape on the
 Blaster. Instead place the blaster on either side, or on the top or bottom of the IR eye or
 window, with the tip of the blaster facing the IR eye or window. See below for illustration of
 where IR signal shoots from on IR Blaster:



IR RECEIVER (RX)

To control the source: Plug IR Receiver into IR IN port of receiver unit (HD4KEX30-RX); place receiver at or near display.

Note: Due to possible differences in 3rd party IR cables, please use the IR cables that came with the product

NOTICE

- Vanco HDMI and Cat5e/6 cables are strongly recommended for use with this product to ensure best results.
- 2. Incorrect placement of IR Transmitter and Receiver may result in the failure of the IR extenders. Please check carefully before plugging in the IR extender to the respective IR sockets.
- 3. The transmission length is largely affected by the type of Cat5e/6 cables utilized, the type of HDMI sources, and the type of HDMI display. The testing result shows solid UTP cables (usually in the form of 300m [1,000ft] bulk cables) can transmit a lot longer signals than stranded UTP cables (usually in the form of fixed length patch cords). Shielded STP cables are better suited than unshielded UTP cables. A solid UTP Cat5e/6 cable shows longer transmission range than stranded STP Cat-6 cable. For long extension applications, use solid UTP/STP category cables.
- 4. EIA/TIA-568-B termination (T568B) for Cat5e/6 cables is recommended for better performance.
- 5. To reduce the interference among the unshielded twisted pairs of wires in Cat5e/6 cables, one can use shielded STP cables to improve EMI problems, which worsens in long cable transmission.
- The quality of Cat5e/6 cables can have a major effect on how long the transmission limit can achieve and quality of picture, the actual transmission range is subject to the Cat5e/6 cable utilized. For the best results, Cat6 is recommended.
- 7. If your HDMI display has multiple HDMI inputs, it is found that the first HDMI input [HDMI input #1] generally can produce better transmission performance among all HDMI inputs.



TROUBLE-SHOOTING

- Best results are usually achieved when the source and display resolutions are the same. If resolutions
 differ, the extenders will try to adjust the signal to match the resolution of the HDTV with the lowest
 resolution. This will result in a picture with a lower resolution on the other HDTV sets.
- If you do not get audio and video, access the "setup" menu on the TV to adjust the audio and video settings. If the HDMI control circuit cannot establish a handshake, then there usually will be no audio or video in addition to a blue or black screen with a statement similar to "this protocol not supported" or "weak signal".
- If the above mentioned messages display, reset the receiver by disconnecting the power supply. You can also disconnect all of the HDMI and power cables, wait 15 minutes for any voltages to decay and then reconnect all of the cables.
- 4. If you are still encountering issues, attempt the "hot-plug" concept. With all of the HDMI cables disconnected, turn on the source and plug in the HDMI cable into it's output, then power up the Vanco unit and plug the HDMI cable into it's input, finally turn on the display and plug the HDMI cable from the receiver into it. This activates all of the devices in corresponding order and results in a signal being plugged into a device that is on and will attempt to connect the signal.
- 5. Most of the major source and display manufacturers employ a proprietary control channel to communicate between devices from the same manufacturer (CEC). Sometimes this can interfere with the HDMI control circuit or the authentication of the signal. Call the manufacturer if you experience this issue. Sometimes a player, an audio/video receiver, or a cable/satellite box may not have the latest software update, usually this can be downloaded from the manufacturer's website.
- If you have problems with the IR control circuit, make sure that the IR RX pigtail is plugged into extender receiver and pointed at the display, and the IR TX pigtail is attached to the extender sender and pointed at the source.

SAFETY AND NOTICE

The HD4KEX30 has been tested for conformance to safety regulations and requirements, and has been certified for international use. However, like all electronic equipment, the HD4KEX30 should be used with care. Please read and follow the safety instructions to protect yourself from possible injury and to minimize the risk of damage to the unit.

- · Follow all instructions and warnings marked on this unit.
- Do not attempt to service this unit yourself, except where explained in this manual.
- · Provide proper ventilation and air circulation and do not use near water.
- · Keep objects that might damage the device and assure that the placement of this unit is on a stable surface.
- · Use only the power adapter and power cords and connection cables designed for this unit.
- · Do not use liquid or aerosol cleaners to clean this unit.
- · Always unplug the power to the device before cleaning.

LIMITED WARRANTY

With the exceptions noted in the next paragraph, Vanco warrants to the original purchaser that the equipment it manufactures or sells will be free from defects in materials and workmanship for a period of two years from the date of purchase. Should this product, in Vanco's opinion, prove defective within this warranty period, Vanco, at its option, will repair or replace this product without charge. Any defective parts replaced become the property of Vanco. This warranty does not apply to those products which have been damaged due to accident, unauthorized alterations, improper repair, modifications, inadequate maintenance and care, or use in any manner for which the product was not originally intended.

Items integrated into Vanco products that are made by other manufacturers, notably computer hard drives and liquid crystal display panels, are limited to the term of the warranty offered by the respective manufacturers. Such specific warranties are available upon request to Vanco. A surge protector, power conditioner unit, or an uninterruptible power supply must be installed in the electrical circuit to protect against power surges.

If repairs are needed during the warranty period the purchaser will be required to provide a sales receipt/sales invoice or other acceptable proof of purchase to the seller of this equipment. The seller will then contact Vanco regarding warranty repair or replacement.

LIABILITY STATEMENT

Every effort has been made to ensure that this product is free of defects. The manufacturer of this product cannot be held liable for the use of this hardware or any direct or indirect consequential damages arising from its use. It is the responsibility of the user and installer of the hardware to check that it is suitable for their requirements and that it is installed correctly. All rights are reserved. No parts of this manual may be reproduced or transmitted by any form or means electronic or mechanical, including photocopying, recording or by any information storage or retrieval system without the written consent of the publisher.

Manufacturer reserves the right to revise any of its hardware and software following its policy to modify and/or improve its products where necessary or desirable. This statement does not affect the legal rights of the user in any way.

TECHNICAL SUPPORT

In case of problems, please contact Vanco Technical Support by dialing 1-800-626-6445. You can also email technical support issues to techsupport@vanco1.com.

When calling, please have the Model Number, Serial Number (affixed to the bottom of the unit) and Invoice available for reference during the call.

Please read this Instruction Manual prior to calling or installing this unit, since it will familiarize you with the capabilities of this product and its proper installation.

All active electronic products are 100% inspected and tested to insure highest product quality and troublefree installation and operation. The testing process utilizes the types of high-definition sources and displays typically installed for entertainment and home theater applications.

For additional information, such as helpful installation videos, glossary of terms, etc. please visit vanco1.com

Vanco® International

506 Kingsland Drive Batavia, Illinois 60510 call: 800.626.6445

fax: 630.879.9189 visit: www.vanco1.com