



Updating the firmware for the EVO-IP system


Below are the steps that are required to perform a firmware update locally on the EVOIPCTL1 control box. Please check the product webpage at www.vanco1.com for the most up to date firmware.

1. Connect to the EVO-IP web based GUI by entering the IP address of the EVOIPCTL1 control box, or by typing <http://evo-ip.local> into any web browser on the local network.
2. Enter in the account username and password (both are **admin** by default).



EVOLUTION

3. click on the **Smart Controller** mode and a new window or tab will open on the browser.



4. Once the new window or tab opens, enter the username and password (both are **admin** by default), then click “Login”.

