

Vanco EVSW1040 URC Driver V1.0 rev20160408

Overview

This document details how to integrate a Vanco EVSW1040 HDMI Switch into URC systems.

Ensure that you have setup and can control your Vanco EVSW1040 HDMI Switch with the controls on the front of the Switch. This driver communicates with the Vanco EVSW1040 HDMI Switch using RS-232, and requires that it be connected to the URC system in order to control it.

Installation

- Add the URC driver to Accelerator's "CustomDrv" folder, located in Documents\Universal Remote Control, Inc\URC Accelerator.
- Add the driver to your project. Select the driver from the RS232 Database for Serial control. **(Accelerator STEP 4)**
- Select the connected RS232 Port. **(Accelerator STEP 5)**
- Configure the inputs and output under "INPUTS". **(Accelerator STEP 7)**
- Accelerate menus. **(Accelerator STEP 10)**
- Configure macros, device specific functions are available for each output. **(Accelerator STEP12)**
- Download and Test!

