

PA360 Battery Replacement

The included battery in the PA360 is a lithium-ion battery. If not regularly used, the battery must be conditioned every 6 months to avoid battery failure. To condition the battery, simply plug in the PA360 to power, and charge to full level.

To replace the battery on the PA360, the replacement part # is BATT-360. See below for instructions to replace the battery:

1. At the bottom of the PA360, you will find a panel with three Phillips screw heads, unscrew all three and lift panel up to expose the battery



2. Once the battery is exposed, locate the connector. The connector has one tab, press the tab and the opposite end, and pull the connector out to disconnect the battery







3. Place the new battery (BATT-360) on the foam pad, within the specific cutout for the battery



- 4. Connect the battery's male connector to the PA360's female connector. Ensure it is a secure connection
- 5. Reinstall the panel and screw back in
- 6. Plug in the PA360 and fully charge the battery
- 7. After fully charging, turn on the PA360 and test all functions

