

Analog to Digital Audio Converter

DEAR CUSTOMER

Thank you for purchasing this product. For optimum performance and safety, please

For optimum perior mance and salety, please

read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

FEATURES:

- Converts an analog stereo audio signal from L/R Input to Digital Coaxial or Toslink outputs
- Supports uncompressed 2-channel LPCM digital audio signal output
- Supports output sampling rate at 48 KHz
- Provides electromagnetic noise-free transmission
- Power Supply: 5V DC
- UL Listed

SPECIFICATIONS:

Input Audio	Stereo R/L
Output Audio	LPCM
Input audio connector	2XRCA (R/L)
Output audio connector	Toslink 1XRCA (Coaxial)
Audio Connector Audio	Toslink Audio and Digital
Sampling rate	48KHz
Size(L-W-H)	1.625" W x 1" H x 2.5" D
Weight (Net)	78g
Limited Warranty	1 Year Parts and Labor
Operating Temperature	0 to + 70 Degrees C
Operating Humidity condensation)	10% to 85 % RH (no
Storage Temperature	10 to +80 Degrees C
Storage Humidity condensation)	5% to 90 % RH (no
External Power Supply	5V DC@2A
Power Consumption	0.5 watts (max)
Converter Unit	FCC,CE,UL
Power Supply	UL,CE,FCC
AC Power Adapter	US standard

CONNECT AND OPERATE

Before installation, please make sure all devices you wish to connect have been turned off.

- Connect the audio source device to the Converter using appropriate R/L cable.
- 2. Connect the A/V Receivers or Amplifiers to the Converter using appropriate Toslink or Coaxial cables.
- 3. Insert the DC side of 5v power supply into the converter and then connect the AC side of the power supply into the wall outlet.

Attention: Insert / Extract cable gently.

PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- 1. Main unit (Analog to Digital Audio Converter)
- 2. 5V DC Power Supply
- 3. User's Manual



