

Specifications		
Connectivity	USB-C 2.0	
Power	802.3af PoE	
Power consumption	9W (max)	
Sample rate	48kHz	
Bit depth	24-bit	
Operation temperature	-5° ~ 55°C	23°F ~ 131°F
Storage temperature	-25° ~ 70°C	-9°F ~ 158°F
Dimensions (W x H x D)	113mm x 48mm x 26mm	4.5in x 1.9in x 1in
Weight	165g	8.5oz



USB-C Dante Audio Adapter

Please read these instructions carefully before use and keep this guide for future reference. The part number, serial number, and invoice must be available when requesting support.

Package contents:

- (1) BDUSBC Dante audio adapter
- (1) USB-C to USB-C cable
- (1) USB-C to USB-A cable
- (1) Product manual

Vanco Tech Support

Phone: 800-626-6445

Email: techsupport@vanco1.com

Web: www.vanco1.com/tech-support




BDUSBC Product Manual

©2026 Vanco International LLC



Panel Descriptions

1	Dante network communication RJ45 port	Solid green: system ready and online
		Flashing green: connected to Dante controller
		Flashing amber: data transfer
2	USB-C	USB-C 2.0



Connection Diagram

1	Connect the Dante AVIO adapter's RJ45 into a PoE port of the switch with a known working Cat5e/6 cable.
	If your switch does NOT have PoE, use a PoE injector between the adapter and the switch.
2	Connect the adapter's USB-C port to your computer or device.
3	Check the RJ45 ports on the adapter and switch to confirm functionality.
4	Download and open Dante Controller, or other 3rd party software, to locate, name, and route the audio.
	The Dante AVIO device is limited to a 2x2 configuration with 2 independent input channels and 2 independent output channels.

