HDMI® EXTENDER

over single Cat5e/Cat6 Cable



Vanco Part Number EVEX2005

HDMI® Extender over Single Category 5e/6 Cable



www.vanco1.com • 800.626.6445



DEAR CUSTOMER

Thank you for purchasing this product.

For optimum performance and safety, please

read these instructions carefully before connecting, operating or
adjusting this product. Please keep this manual for future reference.

This product is 100% inspected and tested in the United States to verify HDMI performance parameters.

WARNING

- 1. Do not expose this unit to water, moisture, or excessive humidity.
- Do not install or place this unit in a built-in cabinet, or other confined space without adequate ventilation.
- To prevent risk of electrical shock or fire hazard, due to overheating do not obstruct unit's ventilation openings.
- 4. Do not install near any source of heat, including other units that may produce heat.
- 5. Do not place unit near flames.
- 6. Only clean unit with a dry cloth.

- Unplug unit during lightening storms or when not used for an extended period of time. A surge protector is strongly recommended.
- 8. Protect the power cord from being walked on or pinched, particularly at the plugs.
- 9. Use unit only with accessories specified by the manufacturer.
- 10. Refer all servicing to qualified personnel.

CAUTION

HDMI is a very complex technology requiring continuous authentication of the signal and the same video resolution and audio settings on all electronic equipment in the system. When there are multiple sources and displays, the video resolution and audio setting on all connected units must be adjusted to correspond with that of the display having the lowest video and audio capability.

FEATURES

INTRODUCTION

The Evolution by Vanco EVEX2005 HDMI Extender over Single Cat5e/6 with Bi-directional IR and EDID management extends high definition video and audio signals and IR, at a distance of up to 131ft/40m over a single Cat5e/6 cable. Features EDID management, which allows and encourages source and display "handshake" for seamless integration. The result is an easy and flexible installation with low maintenance. With only one cost effective Cat5e/6 cable, high definition sources with HDMI outputs can be connected to high definition displays with HDMI inputs over long distances. Deep color video, DTS-HD or Dolby TrueHD audio, and HDCP is supported and compatible with the EVEX2005. In addition, EVEX2005 is also equipped with bidirectional IR pass-through which allows for source or display control.

The EVEX2005 includes two units: transmitting unit (EVEX2005-TX) and receiving unit (EVEX2005-RX). The transmitting unit is used to capture the HDMI input with IR signals and carries the signals via one cost effective Cat5e/6 cable. The receiving unit is responsible for equalizing the transmitted HDMI signal and reconstructing IR and serial control signals. The EVEX2005 offers the most convenient solution for HDMI extension over a single Cat5e/6 with long distance capability, and is the perfect solution for any application.

HDMI® over Single Cat5e/Cat6 Cable Extender Part # EVEX2005

- Allows HDMI audio/video signals to be transmitted using a single Cat5e or Cat6 Cable
- Wide band Bi-directional IR system allowing for control of source or display (IR accessories included)
 Wideband IR signal from 20KHz to 60KHz
- Transmission Range: Extends 1080p resolution up to 131ft/40m over Cat5e/6
- Works with HDMI and HDCP compliant devices
- Supports up to 1080p High Definition resolution
- Features EDID management which supports default HDMI EDID and has the ability to learn the EDID of display equipment
- Features EQ distance dial for perfect transmission and reception of HDMI signals
- Supports HDMI Deep Color & 3D
- Extends HDMI transmission up to 40m (131ft) from the HDMI source at Full HD 1080p 24-bit
- HDCP 2.0 compliant
- EDID manual select control Supports copy EDID and auto EDID learning
- Pure unaltered uncompressed 7.1ch digital HDMI over a single Cat5e/6 cable transmission
- Supports DTS-HD and Dolby TrueHD high bit rate audio
- Allows cascading to create a larger distribution system.
- · Wall mounting housing design for easy and robust installation
- Fully compatible with any Evolution by Vanco product
- Dimensions: 3.6" (91mm) W x 1.1" (28mm) H x 2.8" (71mm) D



SPECIFICATIONS

TECHNICAL SPECS	5/41181 4 8	
HDMI Compliance	UDMI Doop Colon Full 2D	
HDCP Compliance	'	
Video Bandwidth	· ·	
Video Support		
HDMI over UTP	Full HD (1080p)-40m (1311t) (CALX); HD	
Audio Support	. Surround Sound (up to 7.1 ch) or stereo digital audio	
Signal Equalization	. 8-level digital control at RX	
Input TMDS Signal	. 1.2 Volts (peak to peak)	
Input DDC Signal	. 5 Volts (peak to peak, TTL)	
ESD protection	(1) Human body model +/- 19kV (air-gap discharge) &	
(contact discharge) (2) Core chipset - +/- 8k V		
PCB stack-upsingle 50	4 layer board (impedance control - differential 100,	
IR pass-thru	. Full-duplex bi-directional	
RS-232 Support	Yes	
Input	(TX) 1xHDMI; (RX) 1xRJ45 + 2x3.5mm	
Output	(TX) 1xRJ45 + 2x3.5mm; (RX) 1xHDMI	
In/Out	1xDIN9	
HDMI source control	Controllable via IR pass-through from RX to TX and	
HDMI connector	Type A 19 pin female	
Min DIN connector	DIN-9	
RJ-45 connector	WE/SS 8P8C with 2 LED indicators	
3.5mm connector	(TX and RX) IR Receiver/ IR blaster	
Rotary control switchequalization	(TX) EDID Mode Selection; (RX) Signal level	
MECHANICAL SPECS		
Housing	Metal enclosure	
Fixedness	Wall-mounting case with screws	
Power supply	(2) 5V2A	
Power consumption	1.5 Watts	
Operation temperature	32-104 degrees F	
Storage temperature	4 - 140 degrees F	
Relative humidity	20-90% RH (no condensation)	

PACKAGE CONTENTS

- EVEX2005 (TX & RX)
- IR Blaster (TX)
- IR Receiver (RX)
- (2) DC 5V in line power supply
- Rack-mounting ear set
- Product Manual

PANEL DESCRIPTIONS

Transmitting Unit





Receiving Unit





- 1. 5 V DC Connect to 5V DC power supply
- 2. HDMI IN Connects to a HDMI source with a HDMI male-male cable
- 3. EDID Rotary Switch see EDID section below
- 4. RJ45 (HDMI Signal Out) Plug in a Cat-5/5e/6 cable that needs to be linked to the transmitting unit
- 5. IR Blaster Infrared 3.5mm socket for plugging in the extension cable of IR blaster
- 6. IR Receiver Infrared 3.5mm socket for plugging in the extension cable of IR receiver
- 7. 5 V DC Connect to 5V DC power supply
- 8. HDMI OUT Connect to a HDMI display with a HDMI male-male cable
- 9. Signal Level Adjust the 8-level equalization control to the received HDMI signals. The HDMI signal level varies from MAX (strongest) to MIN (weakest) for respective transmission length from longest possible range to short distance. Adjust the signal level from MIN to MAX until desired video quality is displayed. Inappropriate signal level setting may cause overpowering issue that would shorten the life of the product)
- 10. RJ45 (HDMI Signal In) Plug in a Cat-5/5e/6 cable that needs to be linked to the receiving unit
- 11. IR Blaster Infrared 3.5mm socket for plugging in the extension cable of IR blaster
- 12. IR Receiver Infrared 3.5mm socket for plugging in the extension cable of IR receiver



EDID

The EDID dip switch allows for EDID learning or to pre-set an EDID to encourage a "handshake" between the display and source.

Auto EDID Learning Mode

- 1. Set "MODE" on the transmitting unit EVEX2005-TX at 7
- 2. Follow the instruction in [Connect and Operate] to set up the EVEX2005
- 3. The LED on the RJ45 of EVEX2005-TX will dim and light again, which indicates the EDID learning procedure is complete
- 4. Turn Rotary Dial back to O
- 5. Turn both transmitter and receiver units off and then power up again to establish setting.

Manual EDID Learning Mode

- 1. Set Learning (Copy) EDID Mode on the Transmitter (TX) unit = "7"
- 2. (SEE DRAWING) FIRST: Connect Transmitter (TX) unit directly to the Flat Panel Display using a HDMI cable. SECOND: Connect the 5VDC Power Adapter. The "yellow" Status LED light must blink once for Learning (Copy) EDID to be Successful. Now you can disconnect Transmitter (TX) from Flat Panel Display.

Note - Do not connect Receiver (RX) unit during Learning (Copy) EDID Mode


- 3. Change Transmitter back to Factory Default Setting EDID = "0"
- Proceed to Connect & Operate with Normal Installation (see connect and operate). Wait for Sync Lights (on Transmitter & Receiver) to Stop Flashing
- 5. If no Picture or Signal is on the Flat Panel Display then Power OFF (both Units) & Power ON (both Units). Simply remove the 5VDC Power supplies & reconnect

0 - EDID Full-HD (1080p@60) (1080p@30) (1080p@24) (1080i@60 (720p@60) - 24bit 2D video & 7.1ch audio

- 1 EDID Full-HD(1080p@60) 24bit 2D video & 2ch audio
- 2 EDID Full-HD(1080p@60) 24bit 3D video & 7.1ch audio
- 3 EDID Full-HD(1080p@60) 24bit 3D video & 2ch audio
- 4 EDID HD(1080p@30)(1080i@60)(720p@60) 24bit 2D video & 7.1ch audio
- 5 EDID HD(1080p@30)(1080i@60)(720p@60) 24bit 2D video & 2ch audio
- 6 EDID Full-HD(1080p@60) 36bit 2D video & 7.1ch audio
- 7 Auto EDID learning/ Manual EDID learning mode



CONNECTION DIAGRAM



CONNECT AND OPERATE

- Connect a source such as a Blu-Ray Player, game console, AV Receiver, Cable or Satellite Receiver, etc. to the HDMI input on the Transmitting unit.
- 2. Connect a display such as an HDTV or HD Projector to the HDMI output on the Receiving unit.
- 3. Connect a single Category 5e/6 up to 131ft/40m to the output of the Transmitting unit, and the other end to the input of the Receiving unit.
- 4. For power, plug both the Transmitting unit and Receiving unit with the included power supplies.

EQ ROTARY DIAL

If you see flickering or blinking image on the display, adjust the EQ rotary switch to improve the cable skew. MAX stands for the strongest HDMI signal level for the longest possible transmission length while MIN stands for the weakest HDMI signal level for short transmission length. Adjust the signal level from MIN to MAX until desired video quality is displayed.

Recommended EQ settings	
Position	Cable Length
0 (MIN)-2	under 15m (49.5ft)
3-5	15-30m (49.5 ft - 99ft)
6-7 (MAX)	30-40m (99ft - 132ft)

If experiencing No Picture, Picture Flashing, or Drop-Signal then proceed to Manual Learning EDID Mode



IR PASS-THROUGH



IR BLASTER (TX)

To control the source: Plug IR Blaster into IR TX port of transmitter unit (EVEX2005-TX); place blaster in front of the IR eye of the source.

To control the display: Plug IR Blaster into IR TX port of receiver unit (EVEX2005-RX); place blaster in front of the IR eye of the display.

IR RECEIVER (RX)

To control the source: Plug IR Receiver into IR RX port of receiver unit (EVEX2005-RX); place receiver at or near display.

To control the display: Plug IR Receiver into IR RX port of transmitter unit (EVEX2005-TX); place receiver in position where it is able to receive remote signals.





NOTICE

- Vanco HDMI and Cat5e/6 cables are strongly recommended for use with this product to ensure best results.
- 2. Incorrect placement of IR Blaster and Receiver may result in the failure of the IR extenders. Please check carefully before plugging in the IR extender to the respective IR sockets.
- 3. The transmission length is largely affected by the type of Cat5e/6 cables utilized, the type of HDMI sources, and the type of HDMI display. The testing result shows solid UTP cables (usually in the form of 300m [1,000ft] bulk cables) can transmit a lot longer signals than stranded UTP cables (usually in the form of fixed length patch cords). Shielded STP cables are better suited than unshielded UTP cables. A solid UTP Cat5e/6 cable shows longer transmission range than stranded STP Cat-6 cable. For long extension applications, use solid UTP/STP category cables.
- 4. EIA/TIA-568-B termination (T568B) for Cat5e/6 cables is recommended for better performance.
- 5. To reduce the interference among the unshielded twisted pairs of wires in Cat5e/6 cables, one can use shielded STP cables to improve EMI problems, which worsens in long cable transmission.
- 6. The quality of Cat5e/6 cables can have a major effect on how long the transmission limit can achieve and quality of picture, the actual transmission range is subject to the Cat5e/6 cable utilized. For the best results. Cat6 is recommended.
- 7. If your HDMI display has multiple HDMI inputs, it is found that the first HDMI input [HDMI input #1] generally can produce better transmission performance among all HDMI inputs.



Performance Guide for HDMI over Category Cable Transmission

Performance rating		Type of category cable		
Wiring	Shielding	CAT5	CAT5e	CAT6
Solid	Unshielded (UTP)	***	****	****
	Shielded (STP)	***	***	****
Stranded	Unshielded (UTP)	*	**	**
	Shielded (STP)	*	*	**
Termination		Please use EIA/TIA-568-B termination (T568B) at any time		



TROUBLE-SHOOTING

- Best results are usually achieved when the source and display resolutions are the same. If resolutions
 differ, the extenders will try to adjust the signal to match the resolution of the HDTV with the lowest
 resolution. This will result in a picture with a lower resolution on the other HDTV sets.
- If you do not get audio and video, access the "setup" menu on the TV to adjust the audio and video settings. If the HDMI control circuit cannot establish a handshake, then there usually will be no audio or video in addition to a blue or black screen with a statement similar to "this protocol not supported" or "weak signal".
- If the above mentioned messages display, reset the receiver by disconnecting the power supply. You can also disconnect all of the HDMI and power cables, wait 15 minutes for any voltages to decay and then reconnect all of the cables.
- 4. If you are still encountering issues, attempt the "hot-plug concept. With all of the HDMI cables disconnected, turn on the source and plug in the HDMI cable into it's output, then power up the Vanco unit and plug the HDMI cable into it's input, finally turn on the display and plug the HDMI cable from the receiver into it. This activates all of the devices in corresponding order and results in a signal being plugged into a device that is on and will attempt to connect the signal.
- 5. Most of the major source and display manufacturers employ a proprietary control channel to communicate between devices from the same manufacturer. Sometimes this can interfere with the HDMI control circuit or the authentication of the signal. Call the manufacturer if you experience this issue. Sometimes a player, an audio/video receiver, or a cable/satellite box may not have the latest software update, usually this can be downloaded from the manufacturer's website.
- If you have problems with the IR control circuit, make sure that the IR RX pigtail is plugged into extender receiver and pointed at the display, and the IR TX pigtail is attached to the extender sender and pointed at the source.

SAFFTY AND NOTICE

The EVEX2005 HDMI Extender over Single Cat5e/6 with Bi-directional IR, been tested for conformance to safety regulations and requirements, and has been certified for international use. However, like all electronic equipments, the EVEX2005 should be used with care. Please read and follow the safety instructions to protect yourself from possible injury and to minimize the risk of damage to the unit.

- Follow all instructions and warnings marked on this unit.
- Do not attempt to service this unit yourself, except where explained in this manual.
- Provide proper ventilation and air circulation and do not use near water.
- Keep objects that might damage the device and assure that the placement of this unit is on a stable surface.
- Use only the power adapter and power cords and connection cables designed for this unit.
- Do not use liquid or aerosol cleaners to clean this unit.
- Always unplug the power to the device before cleaning.

I IMITED WARRANTY

With the exceptions noted in the next paragraph, Vanco warrants to the original purchaser that the equipment it manufactures or sells will be free from defects in materials and workmanship for a period of two years from the date of purchase. Should this product, in Vanco's opinion, prove defective within this warranty period, Vanco, at its option, will repair or replace this product without charge. Any defective parts replaced become the property of Vanco. This warranty does not apply to those products which have been damaged due to accident, unauthorized alterations, improper repair, modifications, inadequate maintenance and care, or use in any manner for which the product was not originally intended.

Items integrated into Vanco products that are made by other manufacturers, notably computer hard drives and liquid crystal display panels, are limited to the term of the warranty offered by the respective manufacturers. Such specific warranties are available upon request to Vanco. A surge protector, power conditioner unit, or an uninterruptible power supply must be installed in the electrical circuit to protect against power surges.

If repairs are needed during the warranty period the purchaser will be required to provide a sales receipt/sales invoice or other acceptable proof of purchase to the seller of this equipment. The seller will then contact Vanco regarding warranty repair or replacement.

TECHNICAL SUPPORT

In case of problems, please contact Vanco Technical Support by dialing 1-800-626-6445. You can also email technical support issues to info@vanco1.com

When calling, please have the Model Number, Serial Number (affixed to the bottom of the unit) and Invoice available for reference during the call.


Please read this Instruction Manual prior to calling or installing this unit, since it will familiarize you with the capabilities of this product and its proper installation.

All active electronic products are 100% inspected and tested to insure highest product quality and troublefree installation and operation. The testing process utilizes the types of high-definition sources and displays typically installed for entertainment and home theater applications.

LIABILITY STATEMENT

Every effort has been made to ensure that this product is free of defects. The manufacturer of this product cannot be held liable for the use of this hardware or any direct or indirect consequential damages arising from its use. It is the responsibility of the user and installer of the hardware to check that it is suitable for their requirements and that it is installed correctly. All rights are reserved. No parts of this manual may be reproduced or transmitted by any form or means electronic or mechanical, including photocopying, recording or by any information storage or retrieval system without the written consent of the publisher.

Manufacturer reserves the right to revise any of its hardware and software following its policy to modify and/or improve its products where necessary or desirable. This statement does not affect the legal rights of the user in any way.



Vanco[®] International 506 Kingsland Drive

Batavia, Illinois 60510 call: 800.626.6445 fax: 630.879.9189 visit: www.vanco1.com